








1. SWITCH OFF MAIN
2. MAKE HOLE PATTERN
3. INSTALL THE BASE PLATE
4. CONNECT LAMP TO THE MAIN
5. DRIVE IN THE SCREWS UNTILL TIGHT
6. SWITCH ON THE MAIN AND LIGHT ON



WA421
L225xW180xH450(mm)
LED-E14-4W



WA420
L370xW225xH300(mm)
LED-E14-4W



WA422
L370xW225xH300(mm)
LED-E14-4W

Lamp: E14-Max20W
 Color: 3000K
 Color rendering: Ra80
 Input: 220V-240V AC
 Frequency: 50/60Hz
 Watt: LED-E14-4W
 Wireless charging 5V / 0.1-1A
 USB charging 5V / 2.1A
 Life span: 20,000hrs
 Operating temp: -20°C - +40°C
 Indoor use only
 IP20
 Dimmable: NO

Cautions: a. Installed by qualified electrician
 b. Use only power-supply supplied by manufacturer for products guarantee